


# MARVIN'S MAZE CONVERSION KIT INSTRUCTION MANUAL


#### SNK ELECTRONICS CORP.

3043 KASHIWA STREET, TORRANCE, CALIF. 90505 Phone: (213) 539-2744


TLX: 182426 SNK CORP.


# PARTS LAYOUT & NUMBER OF ROM







## PARTS LAYOUT & NUMBER OF ROM





# PARTS LAYOUT & NUMBER OF ROM





1 DC POWER SUPPLY CONNECTOR ( VHR-6N )

CN4

PIN	SIGNAL					
1	± 5 V	RED				
2	+ 5 V	"				
3	O V	BLACK				
4	0 V	"				
5	N C					
6	+ 1 2 V	YELLOW				

PIN	SIGNAL	
1	+ 5 V	RED
2	+ 5 V	"
3	o v	BLACK
4	0 V	"
5	ИС	
6	NС	


2 SIGNAL CONNECTOR ( PS - D4C - 40 : JAE )


cn3

PIN	SIGNAL		PIN	SIGNAL	
A 1	0 V		B 1	0 V	
2	COIN		2	NC	
3	SERVICE SW	NOTE 1	3	1 PLAYER SELECT	
4	2 PLAYER SELECT		4	N C	
5	NС		5	N C	
6	0 V		6	0 V	
7	1 PLAY UP		7	1 PLAY DOWN	
8	" LEFT		8	" RIGHT	
9	" FIRE		9	" PUSH 2	NOTE 3
10	N C		10	N C	
11	ис		11	N C	
12	2 PLAY UP	NOTE 2	12	2 PLAY DOWN	NOTE 2
13	" LEFT	//	13	" RIGHT	"
14	" FIRE	<b>"</b>	14	# PUSH 2	NOTE 3
15	ИC		15	N C	
16	VIDEO SYNC		16	VIDEO BLUE	
17	" GREEN		17	" RED	
18	N C		18	" ov	
19	SPEAKER (-)		19	SPEAKER (+)	
20	N C	2000	20	N C	


- (NOTE 1) COIN INPUT CAN BE USED FOR SERVICE INPUT. REFER TO WIRING DIAGRAM (A 2003 F).
- (NOTE 2) THE WIRING FOR 2 PLAYER IS JUST FOR TABLE TYPE.
- (NOTE 3) 1 PLAY PUSH 2 EXTRA FOR THE FUTURE GAMES.
- (NOTE 4) DO NOT USE EMPTY PINS.
- (NOTE 5) THE SPECIFICATION ON COIN COUNTER IS +5V POWER USED ONLY.
  THE CALCULATING SPEED 600 COUNTS/M. (duty 50%)

	To a contract of the contract	Tees	The Part of the Control of the Contr	T.S.	
APPR :	CHECK	OPG -	SNK ELECTRONICS	140	/





## 1 INSTRUCTION ON MAIN P. C. BOARD



### 2 DIP SW SETTINGS

2 - 1 DIP SW 1

2-2 DIP SW 2

	S W No.	8	7	6	5	4	3	2	1	SW No	8	7	6	5	4	3	2	ĩ
NUMBER OF PL	AY 1					·	OFF	ON	אס	1 st BONUS 10000						ON	ON	O N
"	2				F0 3046		OPF	ON	OFF	20000	X					ON	ON	OF
"	3				1		OPP	077	ои	30000	- 615 Vector					ON	OFF	0.8
"	5						OFF	OFF	OPP	40000						ON	OFF	OF
PLAY CAN BI		S.					ON			50000	200					OFF	ON	ON
COIN/PLAY	1/1		OFF	ом	ON	ON				60000			lane .	13503-3	2000 00100	OFP	ON	OF
"	1/2		OFF	ON	ом	OFF				70000						OFF	OFF	ON
"	<b>√3</b>	85 92	OFF	ON	OFF	ON				80000						OFF	OFF	QFI
"	L/5		OFF	ON	OFF	OFF				2 nd BONUS NO USED				ON	ON			30
"	1/6		OFF	OFF	ои	ON				#1 at BONUS	•			ON	OPP		_	
"	2/1		OFF	OFF	ON	OFF				* +I st×2				OFF	ON	10.00		
11	3/1		OPF	OFF	OPF	ои				" +1st×3				OPF	OFF			
"	5/1		OFF	OFF	OPF	OPP				MUSIC IN ATTRACT MODE			OFF					
FREE PLAY			ON		1571					TABLE		OPP			110000			
SCREEN S	гор	ON								SWITCH THE SCREEN	OFF							


#### THE EXAMPLE OF 2ND BONUS:


lst BONUS = 30000 2 nd BONUS = 1 st  $\times$  2


2 nd BONUS POINT = 1st + 1st  $\times$  2 = 30000 + 30000  $\times$  2 = 90000


#### SWITCH THE SCREEN


WHEN THE DIRECTION OF PLAYER 1 IS INCORRECT, USE "ON".


























	- REAIZIOH	ORG.	SNK ELECTRONICS
		ļ.	KUSUK MARVIN'S MAZE
1			KUSUKI SOUND SCHEMATIC
			APRO 23. 3.18 A 2003 UC 03 — 0